

---

# **Fourier Transforms**

**( Superposition take 3)**

## **ECE 211 Circuits I**

### **Lecture #31**

Please visit [Bison Academy](#) for corresponding  
lecture notes, homework sets, and solutions

---

---


## Superposition (review)

Superposition allows you to analyze circuits with multiple sinusoidal inputs. If this is the case

- Treat the problem as  $N$  separate problems, each with a single sinusoidal input.
- Solve each of the  $N$  problems separately using phasor analysis
- Add up all of the answers to get the total output.

Suppose your circuit has an input that *isn't* a sum of sinusoids.

- One solution is to approximate the input with two sine wave (what we did last lecture)
- A second solution is to define the input in terms of sine waves (this lecture)



---

# Fourier Transform

If  $x(t)$  is periodic in time  $T$

$$x(t) = x(t + T)$$

then you can express  $x(t)$  as

$$x(t) = a_0 + \sum_{n=1}^{\infty} a_n \cos(n\omega_0 t) + b_n \sin(n\omega_0 t)$$

where

$$\omega_0 = \frac{2\pi}{T}$$

---

---

## Translation:

$$x(t) = a_0 + \sum_{n=1}^{\infty} a_n \cos(n\omega_0 t) + b_n \sin(n\omega_0 t)$$

### Going right to left

- *If you add up a bunch of signals which are periodic in time  $T$ , the result is also periodic in time  $T$*
- *Duh.*

### Going right to left:

- *If a signal is periodic and is not a sine wave, it is made up of sine waves which are harmonics of the fundamental.*

---

## Finding Fourier Coefficients:

$$x(t) = a_0 + \sum_{n=1}^{\infty} a_n \cos(n\omega_0 t) + b_n \sin(n\omega_0 t)$$

Analytic Solution: Integration. Wait for ECE 343 to do this

Numeric Solution: Use Matlab

$$a_0 = \text{mean}(x)$$

$$a_n = 2 \cdot \text{mean}(x \cdot \cos(n\omega_0 t))$$

$$b_n = 2 \cdot \text{mean}(x \cdot \sin(n\omega_0 t))$$

---

---

## Proof: $a_0$ :

All sine waves are orthogonal. The DC term is

$$a_0 = \text{mean}(x)$$

$$a_0 = \text{mean}\left(a_0 + \sum_{n=1}^{\infty} a_n \cos(n\omega_0 t) + b_n \sin(n\omega_0 t)\right)$$

$$a_0 = \text{mean}(a_0) + \text{mean}(a_1 \cos(\omega_0 t)) + \text{mean}(a_2 \cos(2\omega_0 t)) + \dots$$

The mean of a sine wave is zero

$$a_0 = a_0 + 0 + 0 + \dots$$

---

---

## Proof: $a_1$

$$x(t) = a_0 + \sum_{n=1}^{\infty} a_n \cos(n\omega_0 t) + b_n \sin(n\omega_0 t)$$

$$a_1 = 2 \operatorname{mean}(x \cdot \cos(\omega_0 t))$$

$$a_1 = 2 \operatorname{mean}((a_0 + a_1 \cos(\omega_0 t) + b_1 \sin(\omega_0 t) + \dots) \cdot \cos(\omega_0 t))$$

$$\begin{aligned} a_1 &= 2 \cdot \operatorname{mean}(a_0 \cdot \cos(\omega_0 t)) \\ &\quad + 2 \cdot \operatorname{mean}(a_1 \cos(\omega_0 t) \cdot \cos(\omega_0 t)) \\ &\quad + 2 \cdot \operatorname{mean}(a_2 \cos(2\omega_0 t) \cdot \cos(\omega_0 t)) \\ &\quad + \dots \end{aligned}$$

The mean of a sine wave is zero. The mean of  $\cos^2(t)$  is  $1/2$

$$a_1 = 0 + 2 \cdot \frac{a_1}{2} + 0 + \dots$$

$$a_1 = a_1$$

etc.

---

---

## Time Scaling:

Through a change of variable, you can make the period anything you want.

Making the period  $2\pi$  makes the problem easier:

$$T = 2\pi$$

$$\omega_0 = \frac{2\pi}{T} = 1$$

$$x(t) = a_0 + \sum_{n=1}^{\infty} a_n \cos(nt) + b_n \sin(nt)$$




---

# Common Fourier Transforms: Sine Wave

$$x(t) = 3 \cos(5t)$$

Fourier Transform:


$$x(t) = 3 \cos(5t)$$



# Square Wave

$$x(t) = \begin{cases} 5V & \cos(5t) > 0 \\ 0V & \text{otherwise} \end{cases}$$

$$x(t) \approx 2.5 + 3.18 \cos(5t) - 1.05 \cos(15t) + 0.64 \cos(25t) + \dots$$




---

# Triangle Wave

$$x(t) = x(t + 2)$$

$$x(t) = \begin{cases} t & 0 < t < 1 \\ 2 - t & 1 < t < 2 \end{cases}$$

$$x(t) = 0.5 - 0.405 \cos(\pi t) - 0.045 \cos(3\pi t) - 0.016 \cos(5\pi t) + \dots$$




---

# Half-Rectified Sine Wave

$$x(t) = x(t + 2\pi)$$

$$x(t) = \begin{cases} 5 \sin(t) & \sin(t) > 0 \\ 0 & \text{otherwise} \end{cases}$$

$$x(t) \approx 1.591 + 2.5 \sin(t) - 1.061 \cos(2t) - 0.212 \cos(4t) + \dots$$



---

## Summary:

If a waveform is periodic in time  $T$ ,

It can be expressed as a sum of sine waves.

This allows us to use superposition to analyze the circuit for the given input without resorting to approximations.

---